

Monkey Tail Operating Stay Bar Fitting Instructions

To fit this Stay Bar you will require the following tools:

- Pencil
- Tape Measure
- Drill
- Crosshead Screwdriver

Installing a Monkey Tail Operating Stay Bar

- 1 Mark the location of the pin **B** on the bottom window frame. The centre of the left screw hole must be at 126mm from left window frame and 13mm from the edge of the bottom window frame.

- 2 Drill the hole using 3mm drill bit and install the pin.

Note: For right hand, install the pin at 126mm from right window frame using right screw hole of the pin.

- 3 Mark the location of the Fixing Bracket on the window sash. The centre of the right screw hole of bracket must be at 25mm from centre of left screw hole of the Pin. The height of the screw hole must be 13mm from the bottom window frame.

Ensure the stay rests well on the clip without any movement. Install the brackets **C**.

NOTE

Please choose to install the stay on either 'Right-hand side' or 'Left-hand side' of the window before following the instructions.

