



Monkey Tail Dummy Stay Bar Fitting Instructions

To fit this Stay Bar you will require the following tools:

- Pencil
- Tape Measure
- Drill
- Crosshead Screwdriver

Installing a Monkey Tail Dummy Stay Bar

- 1 Please place the stay bar in position on the window sash (not the frame) **A**.
- 2 Mark the position of each screw with a pencil, drill the required holes **B**.
- 3 Secure in place using the screws provided **C**.

NOTE

This stay is designed to be decorative only (has no operational capabilities). A matching Monkey Tail operating handle is available if required.

